


Front Door Intercoms

(And how to open the door remotely)



When a visitor arrives at the home they will not have access through the locked front doors, so this is what they need to do -

The visitor presses the "call" button to talk to you.



This will cause several phones within the building to ring, the Nursecall system will start to sound, and indicate on the displays that the doorbell has been activated.

You answer the call by picking up the handset on -

a ringing DECT phone by pressing this button

or

by picking up the handset on a ringing standard desk phone



Once you have spoken to the visitor you can then unlock the door from the telephone by slowly pressing the # button 3 times, i.e.

(pause)

(pause)

#

button

You will hear the intercom unit beep in the earpiece once it accepts the door open command (# # #)

Now hang up the phone by replacing the handset.
The Nursecall system will silence within a few seconds.

In the event that you do not need to unlock the door, or forget to press the # button -

Go to the intercom unit that initiated the call.

You will hear an engaged tone (like on a telephone) coming from the unit

Press the "Cancel" button



This will make the intercom hang up.

The Nursecall system will silence within a few seconds.

If you do not carry out this sequence, the Nursecall system will continue to insist that doorbell is still active, and no other visitor will be able to use the intercom until the "Cancel" button is pressed.